

Galaxy Tab™ Connection Kit User Manual



Congratulations on the purchase of your Samsung Galaxy Tab™ Connection Kit by *PPA*. Unique design and superior quality make this 4-in-1, multifunction product the ideal bridge between tablets and digital cameras.

**** Please read this User Guide carefully before using the product ****

The contents contained herein may be changed to deliver superior quality service to the customer. To maintain perfect product performance, never use the product in cold, hot, dusty or wet areas.

Avoid use in the following conditions:

- > Moist, wet, under water
- > Near a heater, or other high-temperature devices
- > When use might cause product to be dropped or damaged

Manufacturer warranty **VOID** with any attempt to open and/or repair product

Product Overview

Introduction:

Effortlessly import all types of files to your Samsung Galaxy Tab™ via 4-in-1 Connection Kit. Directly transfer files from SD/SDHC, Micro SDHC and USB, via multiport connectors.

Product features:

- 4-in-1 connection kit for Samsung Galaxy Tab™ & Tab™ 2
- Import images, videos, audio and document files (such as MS word, PDF, etc) directly from digital camera, SD/SDHC, Micro-SDHC and USB host
- Micro-USB cable connection for charge function
- LED status indicator

Package Contents


- Connection Kit for Samsung Galaxy Tab™
- Users Manual
- Micro USB Cable

Note: The micro-USB cable provided is specially designed to support 1.5A current. It is strongly suggested not to use any third-party micro-USB cable other than the one provided.

Compatibility

- Samsung Galaxy Tab™ 10.1, 8.9, 7.7 and 7.0 Plus
- Samsung Galaxy Tab™ 2 10.1 and 7.0

Appearance and Interface Description



Number	Name	Function description
1	Micro USB Connector	Connect SAMSUNG Galaxy Tab™
2	LED indicator	USB or memory card instruction
3	USB Host	Read U disk, digital camera, hard disk and keyboard
4	Micro SD card slot	For Galaxy Tab™ Read Micro SDHC Card
5	SD/SDHC card slot	Galaxy Tab™ read SD Card
6	Micro USB	Sync with PC and charge via original adapter

Working status LED indicator

Green: USB host is activated

Red: SD/SDHC and Micro SD are activated

Blue: Micro USB is activated

Function Instructions

Using standard USB Type A

When connecting 4-in-1 connection kit with Samsung Galaxy Tab™, LED will light up green, even when the USB drive is connected with it. Samsung Galaxy Tab™ then will recognize the USB flash device and will read the picture and video files automatically. You can also choose the files you need to import to Samsung Galaxy Tab™ from: MyFiles/Root/Storage/USB/SDA or My Files/Root/USB DrivveA on Android 4.0

Using SD/SDHC or Micro-SD card

When connecting the 4 in 1 kit with the Samsung Galaxy Tab™, the LED will light up in green. Once the


SD or Micro-SD card is connected, the green LED will turn to red. Samsung Galaxy Tab™ then will recognize the USB flash device and will read the picture and video files automatically. You can also choose the files you need to import to Samsung Galaxy Tab™ from: File search path: MyFiles/Root/Storage/USB/SDA or MyFiles/Root/USB DriveA on Android 4.0



Note: Once complete, use the “disable USB device” feature before disconnecting

Connecting Digital Cameras

When connecting the 4-in-1 connection kit with the Samsung Galaxy Tab™, the LED will turn green. Insert the USB connector, then power on digital camera. Samsung Galaxy Tab™ will recognize USB flash device and will read picture and video files automatically. You can also choose the files you need to import to Samsung Galaxy Tab™ from: (File search path: MyFiles/Root/Storage/USB/SDA or MyFile/Root/USB/USB DriveA on Android 4.0



Note: Once complete, use the “disable USB device” feature before disconnecting

Charging through the Micro-USB cable using the original Samsung AC adapter

Connect 4-in-1 connection kit with the Samsung Galaxy Tab™, then connect the Micro-USB cable between kit and the AC charger. (This product does not support third-party USB power adapters).

